



INSTRUCTIONS FOR INSTALLATION

MOUNTING:

CAUTION BE SURE FIREARM IS NOT LOADED

1. Loosen locking screws and slide mounting rails onto any 3/8" grooved receiver.
2. Adjust forward or backward until the device's position is most comfortable for you.
3. Tighten locking screws.

INSTALLING BATTERIES:

CAUTION BE SURE FIREARM IS NOT LOADED

Your DIRECT POINT is powered by one 3 volts "coinstyle" lithium battery.

1. Remove protective plastic cap as shown above
2. To remove the old battery, use a screwdriver or similar implement inserted on the notched side of the compartment to push battery out of the other side.
3. Insert new battery + side down.
4. Replace protective cap.

ZEROING:

The following should be done at an approved range or other safe area. Eye and ear protection is recommended.

1. Activate the illuminated red dot by pushing the on/off switch forward.
2. Test fire three shots at a target. Observe the bullet or pellet strike to adjust the windage and elevation as needed to bring the next test group of 3 shots into the center of the target.

NOTE: For windage adjustment, turn the windage adjustment knob clockwise to move the point of impact left and counterclockwise to move the point of impact right. In the same manner, adjust the elevation by turning the elevation knob clockwise to raise the point of impact, and counterclockwise to lower the point of impact.

INSTRUCCIONES DE INSTALACIÓN

MONTAJE:

ATENCIÓN, ASEGURESE QUE EL ARMA NO ESTE CARGADA.

1. Aflojar los tornillos de bloqueo y deslizar la montura en las ranuras de fijación, que deben ser de 3/8" (10 mm. aprox.).
2. Desplace la mira adelante o atrás hasta que la parte del ocular le resulte cómoda.
3. Aprete los tornillos de bloqueo.

INSTALACION DE LA BATERIA:

ATENCIÓN, ASEGURESE QUE EL ARMA NO ESTE CARGADA.

La mira DIRECT POINT lleva una batería de litio del tipo botón de 3 volts. Si el punto rojo iluminado se agranda o no se aprecia, cambie la batería.

1. Quitar la tapa protectora, y retirar la pila con la ayuda de un destornillador o similar.
2. Insertar la batería nueva con el signo + hacia abajo.

REGULACION DE LA MIRA:

Las operaciones que se describen seguidamente, hay que realizarlas en un tunel de tiro u otro lugar que sea suficientemente seguro. Se recomienda proteger los ojos y los oídos.

1. Activar el punto rojo por medio del interruptor lateral, desplazándolo a la posición ON
2. Haga la prueba de tres disparos sobre una diana. Observe si el impacto del balón o de la bala coinciden con el lugar donde ha apuntado, y corrija la elevación y la deriva de acuerdo con la desviación experimentada. Repita otra serie de tres disparos y, si es necesario, corrija de nuevo, y vuelva a ensayar hasta que consiga la diana.

NOTA: Para regular la deriva mueva la rueda de ajuste en sentido horario para desplazar el punto de impacto a la izquierda; hágalo en sentido antihorario para desviar el impacto hacia la derecha. Del mismo modo, girando la rueda de elevación en sentido horario, levantará el punto de impacto, y si lo hace en sentido antihorario lo bajará.