




INSTRUCTION MANUAL

VELOCITY 400 FPS





READ THIS OWNER'S MANUAL COMPLETELY. This airgun is not a toy. Treat it with the same respect you would a firearm. Always carefully follow the safety instructions found in this owner's manual and keep this manual in a safe place for future use.

The air pistol is correctly aimed when the front sight blade is positioned exactly in the notch of the rear sight. The top of the front sight blade should be even with the top of the notch in the rear sight. The bullseye should appear to rest on the top of the front sight.




ALWAYS aim your air pistol in a SAFE DIRECTION. When you are sure of your target and backstop, and the area around the target is clear, put "OFF SAFE" and squeeze the trigger to fire.



CAUTION: You and others with you should always wear shooting glasses to protect your eyes. If you wear reading glasses, you must wear safety glasses intended for use over normal optical reading glasses.

CAUTION: Your backstop should be inspected for wear before and after each use. Discontinue use if the backstop surface shows signs of failure. Always place the backstop in a location that will be safe should the backstop fail. Discontinue the use of a backstop if the projectile rebounds or ricochets. NEVER AIM AT PEOPLE, PETS, OR WATER.



WARNING: NOT A TOY. ADULT SUPERVISION REQUIRED. MISUSE OR CARELESS USE MAY CAUSE SERIOUS INJURY OR DEATH. MAY BE DANGEROUS UP TO 300 YARDS (274 METERS).

THIS IS A HIGH POWERED AIRGUN FOR USE BY THOSE 16 YEARS OF AGE OR OLDER. READ ALL INSTRUCTIONS BEFORE USING. THE PURCHASER AND USER SHOULD CONFORM TO ALL LAWS GOVERNING USE AND OWNERSHIP OF AIRGUNS.

WARNING: THIS AIRGUN CAN CAUSE SERIOUS INJURY OR DEATH. READ AND FOLLOW THE INSTRUCTIONS CAREFULLY. DO NOT LOAD A BB INTO THE GUN UNTIL YOU ARE READY TO SHOOT. IF YOU DO LOAD A BB AND THEN DECIDE NOT TO SHOOT, REMOVE IT EITHER MANUALLY OR BY SHOOTING THE GUN AT A SAFE TARGET. AN UNLOADED GUN WHICH IS "ON SAFE" IS SAFEST. ACCIDENTS HAPPEN FAST. FATALLY WOUNDING SOMEONE IS A TERRIBLE THING. PLEASE SHOOT SAFELY.

CAUTION: Failure to follow the instructions and recommendations in this owner's manual may result in bodily injury including face, eye, and ear injury, blindness or deafness.

OPERATING PROCEDURES



1. Learning the Parts of Your Airgun
2. Operating the Safety
3. Removing and Installing CO₂ Capsules
4. Loading and Unloading Ammo
5. Aiming and Firing Safely
6. Use and Handling of CO₂ Capsules
7. Maintaining Your Airgun
8. Reviewing Safety



1. LEARNING THE PARTS OF YOUR AIRGUN

- | | | |
|--------------------------|---------------------|---------------------|
| 1 Safety | 6 Rear sight: fixed | 11 Follower release |
| 2 Front sight: Fixed | 7 Trigger guard | 12 Puncture screw |
| 3 Trigger | 8 Muzzle | 13 Follower |
| 4 Magazine | 9 Hammer | |
| 5 Magazine release lever | 10 Accessory rail | |

2. OPERATING THE SAFETY



CAUTION: Like all mechanical devices, an airgun safety can fail. Even when the safety is "ON SAFE", you should continue to handle the airgun safely. NEVER point the airgun at any person. NEVER point the airgun at anything you do not intend to shoot.

CAUTION: Always check to make sure the air pistol is unloaded when getting from storage or from another person.


3. REMOVING AND INSTALLING 12g CO₂ CAPSULES

ALWAYS make sure the air pistol is unloaded and "ON SAFE" before removing or installing CO₂.

CAUTION: Remove the magazine from the air pistol before installing the CO₂ capsule.

- Before installing a CO₂ capsule, place one drop of RWS Chamber Lube or airgun lube on the top of the small end of CO₂ capsule.
- NEVER use any tool other than a hex key on the puncture screw. This will void the warranty. Over-tightening may cause injury and can damage the air pistol.

INSTALLATION PROCEDURE:



5 - With the magazine unloaded insert it into the pistol. Point it in a SAFE DIRECTION, put "OFF SAFE" and pull the trigger to fire. If the air pistol does not make a popping noise, the CO₂ is not being discharged. Put back "ON SAFE" and repeat installation procedure making sure to tighten the puncture screw.

REMOVING A CO₂ CAPSULE • It is best to empty a CO₂ capsule by firing an unloaded, unjammed, CO₂ pistol into a SAFE DIRECTION. When the air pistol loses power, allow remaining CO₂ gas to escape by loosening the puncture screw slowly. Then, follow installation procedures in reverse order.

NOTE: Never try to force any CO₂ capsule into or out of place. Do not store your air pistol with a CO₂ capsule in it. If you know you will not be using your air pistol for an extended period of time, safely empty the CO₂ capsule and remove it from the air pistol. This is very important to remember, as it will prolong the longevity of your air pistol seals.

NOTE: A slight seepage of CO₂ gas may occur until puncture screw is tight.

WARNING: USE ONLY 12G CO₂ CAPSULES. ANY ATTEMPT TO USE OTHER TYPES OF GAS CAPSULES COULD BE EXTREMELY DANGEROUS AND COULD RESULT IN SERIOUS INJURY OR DEATH. GASSES OTHER THAN CO₂ COULD RESULT IN AN EXPLOSION OR RUPTURE OF THE AIRGUN.


CAUTION: Keep hands and face away from escaping CO₂ gas. It can cause frostbite if allowed to come in contact with skin. Always make sure the CO₂ capsule is empty before attempting to remove it from the air pistol by slowly turning the CO₂ capsule puncture screw counter-clockwise all the way until you no longer hear the escape of CO₂ gas.

IMPORTANT: Firing the air pistol with too little gas pressure left may cause a BB to get stuck in the barrel.

4. LOADING AND UNLOADING AMMO

We recommend BBs

ALWAYS make sure the air pistol is "ON SAFE" and pointed in a SAFE DIRECTION.



WARNING: ONCE THE MAGAZINE IS LOADED WITH A BB AND INSERTED IN THE PISTOL IT IS CONSIDERED TO BE LOADED. USE EXTREME CAUTION WHEN HANDLING THE AIRGUN. KEEP THE AIRGUN POINTED IN A SAFE DIRECTION. NEVER POINT THE AIRGUN AT ANYONE. ALWAYS TREAT THE AIRGUN AS IF IT WERE LOADED AND READY TO FIRE.

CAUTION: Use only .177 caliber steel BBs. Do not attempt to reuse BBs that have been fired or are deformed. Do not use buck shot, darts, ball bearings, or other foreign objects because they can cause injury to you or someone else or may damage and/or jam the airgun. Use of anything other than .177 caliber steel BBs will void the warranty.

UNLOADING - Keep the air pistol pointed in a SAFE DIRECTION. Remove the magazine. Fire at a SAFE target. Repeat until you are sure the air pistol no longer fires ammunition. You may also unload your air pistol by following the directions listed under "Removing a Jammed BB or Pellet".

CAUTION: Even though you go through the unloading procedure, continue to treat the air pistol as though it were loaded. Do not point at anything you do not intend to shoot.

REMOVING A JAMMED BB - Keep the air pistol pointed in a SAFE DIRECTION and "ON SAFE". Remove the magazine. Insert a .177 caliber ramrod into the muzzle end and carefully push the jammed BB into the breech area and remove. If you are not able to unjam your air pistol, take no further action. Call Umarex USA (479) 646-4210 and ask for the service department. **NOTE:** The barrel could be damaged and the warranty will be void if the proper sized ramrod is not used.

CAUTION: Always point the muzzle in a safe direction. Never place your hand in front of the muzzle.

5. AIMING AND FIRING SAFELY

- Do not shoot at hard surfaces or at the surface of water. The BB may bounce off or ricochet and hit someone or something you had not intended to hit.
- Always choose your target carefully. It is best to shoot at paper bullseye targets, which are attached to a safe backstop. A heavy blanket should be hung behind the target trap to prevent ricochet should you miss the backstop.
- Your backstop should be checked for wear before and after each use. Replace your backstop if the surface is worn or damaged, or if a ricochet occurs.
- Your air pistol is designed for target shooting and is suited for both indoor and outdoor use. Always remember to place your target carefully. THINK about what you will hit if you miss the target.

WARNING: NEVER ASSUME THAT BECAUSE THE AIR PISTOL NO LONGER FIRES A PROJECTILE AND/OR THE MAGAZINE IS REMOVED FROM THE GRIP FRAME THAT A PROJECTILE IS NOT LODGED IN THE BARREL. ALWAYS TREAT THE AIR PISTOL AS THOUGH IT IS LOADED AND WITH THE SAME RESPECT YOU WOULD A FIREARM.

6. USE AND HANDLING OF CO₂ CAPSULES

It is possible that certain conditions may affect a CO₂ capsule, which can impact its proper performance. These conditions include the usage, maintenance and storage at temperatures that are higher or lower than normal outdoors temperatures (59°F/15°C to 69.8°F/21°C). Another condition may be when the gun is fired rapidly.

1. High temperatures can increase pressure in the CO₂ capsule and also within the air gun, leading to higher than standard operating pressure. This excess pressure could cause the gun to malfunction or be permanently damaged. Maximum storage or operation temperature should never exceed 122°F (50°C). This temperature can be reached if you leave the gun under direct sunlight on a bright day. Thus, to ensure proper gun operation, do not expose it to high temperatures or direct sunlight for long periods of time. Otherwise, the CO₂ capsule could overheat and explode, which could damage the airgun and cause injuries or death to people around it.
2. Fast consecutive shooting may produce a decrease of temperature in the gun, as well as the CO₂ capsule. This could result in lower projectile velocities and may even lower gas pressure enough so that the pistol will not fire. This condition can be especially apparent when shooting in cold weather and can be avoided by allowing more time between shots. This permits the gas to increase in temperature and pressure and produce normal velocities.
3. During rapid fire, the muzzle velocity of each shot will diminish. This can affect shooting accuracy and you will get fewer shots per CO₂ capsule.
4. Care should be exercised to insure that the gun is not shot with a CO₂ capsule that is low in pressure. Here are some indicators of insufficient pressure:
 - A) The sound of the shot is not as loud as when the capsule is full.
 - B) The projectile hits the target, but in a lower position than it would with a full CO₂ capsule (that is, the shooting speed has dropped).

WARNING: CO₂ CAPSULES MAY EXPLODE AT TEMPERATURES ABOVE 120° F. DO NOT MUTILATE OR INCINERATE THEM. DO NOT EXPOSE THEM TO HEAT OR STORE CO₂ CAPSULES AT TEMPERATURES ABOVE 120° F.

CAUTION: Never load BBs until you have verified the air pistol will discharge CO₂ properly.

CAUTION: Never attempt to reuse a CO₂ capsule for any purpose.

7. MAINTAINING YOUR AIRGUN

- Before you attempt to perform maintenance on your airgun, make sure the airgun is "ON SAFE" and unloaded, and the CO₂ capsule has been removed.
- Apply 1 to 2 drops of RWS Spring Cylinder Oil or airgun lube onto all other moving parts such as the trigger hinge.
- Tampering with the air pistol or attempts to change the air pistol in any way may make it unsafe to use and will void the warranty.
- If you drop your air pistol, check to see that it works properly before you use it again. If anything seems changed, like a shorter or weaker trigger pull, this may mean worn out or broken parts. Call Customer Service at Umarex USA for assistance before using your air pistol again.

NOTE: Many factors affect airgun performance and velocity, including brand of projectile, type of projectile, lubrication, barrel condition, and temperature.

CAUTION: Oils that contain acid or resin can damage the seals and possibly the air pistol finish.

CAUTION: Before any care, cleaning or maintenance, always be sure your air pistol is "ON SAFE" and unloaded. Keep it pointed in a safe direction. It is important to perform routine inspections and maintain your air pistol properly.

8. REVIEWING SAFETY

- Never point the airgun at any person or at anything you do not intend to shoot.
- Always treat the airgun as though it is loaded and with the same respect you would a firearm.
- Always aim in a SAFE DIRECTION. Always keep the muzzle of the airgun pointed in a SAFE DIRECTION.
- Always keep the airgun "ON SAFE" until you are ready to shoot.
- Always check to see if the airgun is "ON SAFE" and unloaded when getting it from another person or from storage.
- Always keep your finger off the trigger and out of the trigger guard until ready to shoot.
- You and others with you should always wear shooting glasses to protect your eyes. Normal reading glasses are not shooting glasses.
- If your reading or prescription glasses are not safety glasses make sure you wear shooting glasses over your regular glasses.
- Use the proper size BBs for your airgun.
- Never reuse ammunition.
- Do not shoot at hard surfaces or at the surface of water. The BB may bounce off or ricochet and hit someone or something you had not intended to hit.
- Place the backstop in a location that will be safe should the backstop fail.
- Your backstop should be checked for wear before and after each use. All backstops are subject to wear and will eventually fail. Replace your backstop if the surface is worn or damaged or if a ricochet occurs.
- Do not attempt to disassemble or tamper with your airgun. Unauthorized repairs or modifying the function of your airgun in any way may be unsafe and will void your warranty.
- Before you store your airgun, make sure it is unloaded, the CO₂ capsule is removed, and is "ON SAFE."

REPAIR / SERVICE

Do not return defective or damaged product to the dealer. If your airgun needs repair, call Umarex USA (479) 646-4210 and ask for the Service Department or visit www.umarexusa.com. DO NOT ATTEMPT TO DISASSEMBLE IT! Your airgun requires special tools and fixtures to repair it. Any disassembly or modification not performed by Umarex USA will void the warranty.

WARNING: AN AIRGUN THAT IS NOT OPERATING PROPERLY MAY BE DANGEROUS. IT SHOULD BE KEPT SAFELY FROM USE BY ANYONE UNTIL REPAIRED OR DESTROYED. DO NOT TRY TO TAKE THE AIRGUN APART. IT IS DIFFICULT TO REASSEMBLE AND IMPROPER DISASSEMBLY OR REASSEMBLY CAN CAUSE SERIOUS INJURY OR DEATH.

CAUTION: The components of this airgun were engineered and manufactured to deliver optimum performance. Any modification or tampering with this airgun may cause a malfunction, void your warranty and may make it unsafe to use. Any change in performance (such as a lowered trigger pull force and shortened trigger travel) indicates possible modification, tampering, and/or wear. Such airgun should be inspected, replaced, or properly repaired by only qualified Umarex USA personnel. Any airgun that has been dropped should be checked by qualified personnel to ensure that its function has not been affected.

WARRANTY

90 DAY LIMITED WARRANTY

This product is warranted to the retail consumer for 90 days from date of purchase against defects in material and workmanship and is not transferable.

WHAT IS COVERED

Replacement parts and labor.

WHAT IS NOT COVERED

Shipping charges to Umarex USA for defective product and damages caused by abuse or failure to perform normal maintenance as well as any other expense. Consequential damages, or incidental expenses, including damage to property. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

WARRANTY CLAIMS

Warranty Claims and Repair for U.S. and Canadian customers only. Call Umarex USA (479)-646-4210 and ask for the Service Department. If it is determined a return is necessary, you will be issued a Return Authorization Number. Write this number boldly on the box and return the product prepaid to Umarex USA. Your name, address, phone number and a note explaining the defect found must be included in the package. A copy of the original purchase receipt must accompany the return. Include a check made to Umarex USA in the amount of \$9.95 to cover shipping and handling.

IMPLIED WARRANTIES

Any implied warranties, including the implied warranties of merchantability and fitness for a particular purpose, are limited in duration to 90 days from date of retail purchase. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. TO THE EXTENT ANY PROVISION OF THIS WARRANTY IS PROHIBITED BY FEDERAL, STATE, OR MUNICIPAL LAW WHICH CANNOT BE PREEMPTED, IT SHALL NOT BE APPLICABLE. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE AND COUNTRY TO COUNTRY.

H&K USP CO₂ Air Pistol Technical Data

Velocity	400 fps (122 m/s)	Sights	Fixed front and rear
System	CO ₂	Safety	Manual lever
Caliber	.177 (4.5 mm)	Length	7.5 inches (190.5 mm)
Ammunition	Steel BB	Weight	2.18 lbs (0.99 kg)
Capacity	22	Danger Distance	300 yds (274 m)

WARNING: DO NOT BRANDISH OR DISPLAY THIS AIR PISTOL IN PUBLIC - IT MAY CONFUSE PEOPLE AND MAY BE A CRIME. POLICE AND OTHERS MAY THINK IT IS A FIREARM. DO NOT CHANGE THE COLORATION AND MARKINGS TO MAKE IT LOOK MORE LIKE A FIREARM. THAT IS DANGEROUS AND MAY BE A CRIME.